



Direct Drive V3 assembly steps:

1. Place hat with wheel-facing side downwards on work bench
2. Locate disc into hat
3. Take the fixing ring clip end and place into groove in the hat.
4. Carefully work the ring around the hat until fully located in place.